



## Guide 1.1. Headset LED status light




### Step 1

The Headset has a status LED in the **Volume** button.




### Step 2

When the Headset is charging, the LED shows the following status'.



### Step 3


When not charging, the LED will flash blue to show it is in use and connected to the conference.



### Step 4

When talking (using the **PTT** button or Talk-Lock) the LED will be red.

## Guide 1.2. Attaching the Headset to the wearing style




### Step 1

Make sure that the Headset is pointing down from the headband, and press firmly with your fingers on the sides of the Headset (to avoid pressing the **PTT** button).

### Step 2


This is a firm push, and might be firmer than you expect. There will be an audible “click” when the Headset is in place.

### Guide 1.3. Removing the Headset from the wearing style



#### Step 1

To remove the Headset, twist it around until the mic is pointing straight up.



#### Step 2


The mic boom slides along the plastic moulding to detach itself. At first, it may feel like you are going to break the Headset, but don't worry, it's designed to pop off this way.



#### Step 3


Don't try to just pull the Headset out of the mounting.

## Guide 1.4. Adjusting the wearing style




### Step 1

The VoCoVo Link Headset's wearing style can be adjusted in three places...




### Step 2

The top of the headband. The metal is plastic coated to prevent allergy issues, and can be slid in and out of the plastic frame.



### Step 3

The comfort framework. The rubber piece on the plastic frame can be moved up and down as needed, to help relieve pressure.




### Step 4

The top of the ear cushion. The ear cushion can rotate for a more comfortable positioning on the ear.

---


## Guide 1.5. Best positioning of the Headset



### Step 1


Rotate the Headset until the mic boom is pointing towards your mouth. This helps the mic pick up your voice clearly.

## Guide 1.6. Using the PTT button




### Step 1

The large grey button is your Push-to-Talk (**PTT**) button.



### Step 2


When you press the **PTT** button, you'll hear a beep and anything you say will be heard across the conference.



### Step 3


You need to hold the **PTT** button whilst talking (see Talk-Lock for an alternative).

## Guide 1.7. Adjusting the volume



### Step 1


To adjust the volume, press the small black **Volume** button on the Headset.



### Step 2


Each press increases the volume. When at maximum volume, it circles back to the lowest volume.

## Guide 1.8. Enabling and disabling mute




### Step 1

Press and hold the **Volume** button for 3 seconds to activate Mute mode.



### Step 2

You will hear "Mute on" and you won't hear anyone else, or be heard by anyone else on the conference.




### Step 3

Mute will remain on for 3 minutes, unless you press any button to turn it off.




## Guide 1.9. Enabling and disabling Talk-Lock



### Step 1


Talk-Lock lets you talk hands-free without holding the **PTT** button. To activate Talk-Lock, press and hold the **PTT** button, then press the **Volume** button once.



### Step 2

You will hear "Talk-Lock on". Talk-Lock will stay on for 3 minutes unless you press the **PTT** button to turn it off.


## Guide 1.10. Cleaning and care for the Headset and wearing style



### Step 1


You can clean the Headset and headband using 70% isopropyl cleaning wipes. The ear cushion can be cleaned with a very mild detergent solution. Please make sure that the parts are dry before being used or put on charge.

## Guide 1.11. Charging the Headset




### Step 1

The Headset has a status LED in the **Volume** button.




### Step 2

The battery will charge from empty to 90% capacity within 3 hours. It will reach 50% charge in under 1.5 hours.



### Step 3

TIP: When charging, make sure the Headset LED is showing a solid or blinking red or green light. This indicates that the Headset is correctly seated in the Dock and is being charged.



#### Step 4

If the LED is blinking blue or not lit, the Headset is probably not sitting in the charging slot correctly. To correct this, remove the Headset from the charging slot and slide it in again from above until you feel it click.